
GoPro HD Hero2 Back Cover Replacement

GoPro HD Hero2 back cover removal.


Written By: David Hodson




INTRODUCTION

Use this guide to replace a cracked back cover from when your GoPro HD Hero2 took an unexpected tumble.

Step 1 — Back Cover





- Place your thumb on the indentation in the back case on the side of the GoPro.
- Gently press down with your thumb and lift the back cover away from the case to remove it.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 02:34:43 PM.